

Phenolic Resin Installation

10/4/2013

Resin top installation:

1. Predrill all tops for mounting 11/64 drill bit then secure to frame using the attached screws,
****Drill bit not provided**

2. Drill depth to be 1.87" - .50"
****do not over drill**

Use silicone or liquid nail to glue top to frame

3. Use generous amount of silicone or liquid nail to front, rear & side beams

4. Lay top on frame, clamp top to frame for 1-2 hrs,
(might take longer pending ambient temperature,) should you have further questions dont hesitate to call 714-258-7535

